


imp De Mayo V² Knee Positioner Instructions For Use ~ Standard Set Up

1. Replace OR Table Pads with green *imp* pads.

Note: It is not necessary to remove the X-Ray cassette plates.



2. Position patient with gluteal fold at separation of pads.




3. During prep of surgical leg, remove single OR Table Pad.



4. To avoid tearing the drape, create a 3" - 5" fold in the final drape under the buttocks.




5. Place De Mayo V² Knee Positioner in the well to achieve maximum flexion.



imp De Mayo V² Knee Positioner IFU ~ Standard



6. Check flexion for final approval of freedom of the drape to allow full range of motion when the Positioner is locked on drapes.



7. Locate Clamp over drapes so that the groove in the Clamp can accept the Vertical Bar from Base.



Squeeze jaws of the Clamp loading top Knob to middle of the Clamp,

..and, tighten top Knob.



Rotate the Vertical Bar into the groove of the Clamp,

The Vertical Bar must be *vertical*. Ensure that the Vertical Bar touches the clamp's slot edge on both the top and bottom jaws before locking side Knob.



Vertical Bar is not vertical and only touches clamp's top jaw slot edge.





Vertical Bar is in correct position.

..and lock side Knob on Bar.



imp De Mayo V² Knee Positioner IFU ~ Standard


8. Protect your patient from potential Pressure Ulcers. Insert the *imp* Patient Protective Pad into the sterile boot.



9. To insert the pad, position the carriage under the patient's foot with the knee flexed.



Insert the ball of the boot into the carriage and tighten the E-Brake.



Slide the varus tilt lever to Closed.



For additional holding, rotate the Locking Lever to the right.

10. Place the patient's foot in the boot and wrap cohesive bandage around the foot starting with a minimum of six (6) foot wraps, tear, and finish the wrap above the bracket around the calf.



Avoid wrapping cohesive bandage over the bracket on the back of the boot.

imp De Mayo V² Knee Positioner IFU ~ Standard


11. To reposition the leg:

Slide the varus tilt lever to Open,




unlock the E-Brake by turning it counter clockwise,

and loosen the Locking Lever by rotating to the left.



12. Rotate the Carriage Locking Lever to the right to lock the boot.




Set Up Test Procedure



TIGHTEN CLOCKWISE TO LOCK KNOBS AND LEVERS:

- 1 ~ Check all knobs and levers are locked
- 2 ~ Patient is fully protected by imp® foam and cohesive wrap
- 3 ~ Patient's leg can reach full flexion
- 4 ~ Check that Vertical Bar is fully seated and locked



De Mayo V² E^{im} Knee Positioner is a trademark of Innovative Medical Products, Inc.
 U.S. Patent No. 8,132,278
 V² E^{im} Clamp is a trademark of Innovative Medical Products, Inc.
 U.S. Patent No. 7,003,827
 © May 2016 Innovative Medical Products, Inc.
 ALL RIGHTS RESERVED

imp® *Innovative*
 Medical Products, Inc.

87 Spring Lane, PO Box 8028
 Plainville, CT 06062

PH: (860) 793-0391 FAX: (866) 459-1805

Toll Free PH: 1-800-467-4944

www.impmedical.com